

RedBear Beacon B1 – Quick Start Guide



1. Download our open sourced Sample Configuration App
<http://www.redbear.net/support.html>

2. Compile & Run the App on iOS device, it will show
“Searching for B1 in range”.

3. Switch ON the Beacon:
Green light turns on.
(B1 in broadcasting mode)



4. Press the button:
Red light turns on.
(B1 in maintenance mode)



5. App found B1, you can modify
Beacon characteristics:

iPod 1:47 am

Default **B1.Config** Save

UUID
E2C56DB5-DFFB-48D2-B060-D0F5A71096E0

Major 0

Minor 0

Measured Power -55

Status LED

Advertising Interval 250ms

TX Power (dbm) -23 -6 0 +4

Tip: Adjust the value of iBeacon signal “Measured Power” to aid iOS determining more accurate distance estimation, check out our support page.

Please visit <http://www.redbear.net/support.html>
for details of the B1 BLE services & characteristics.

